

PEDAL READY INSTRUCTIONS



- 1** Using a sharp box cutter, carefully cut the box open on the sides, so that you can fold down the front of the box. There is another smaller box, on top of the saddle, where you will find your Shinola Owner's Manual, Q/C checklist with your serial number, and 4mm, 5mm and 6mm Allen wrenches.



- 2** Using the 5mm Allen wrench, loosen the seat post bolt so that you can adjust the height to your preference. The Minimum Insertion Line, which is etched on the seat post, must be inside the frame. A good starting point for the height is to align the top of the saddle with your hip. Straighten the saddle so it is aligned with top-tube of the frame.



3 When the saddle height is set, tighten the seat post bolt with the 5mm Allen wrench. When it's tight, give it one extra turn. See the Shinola Owner's Manual for torque settings.



4 You should have a slight bend to the knee, with your leg fully extended and the ball of your foot over the pedal spindle.

CONGRATULATIONS! Your beautiful Shinola Bixby bicycle is ready to ride. You may want to bring your 5mm Allen wrench with you on your first couple of rides, so that you can micro-adjust the saddle height. If you have any concerns, take your Shinola bicycle to a qualified bicycle mechanic for a safety check. Please read your Shinola Owner's Manual before your first ride.
